



# CANYON 2XL



## NOTICE DE MONTAGE

- 1 – Assembler les 3 arceaux solidarisés.
- 2 – Étaler le double toit sur le sol.
- 3 – Introduire dans leurs fourreaux respectifs, en restant bien à plat, les 3 arceaux. Ne jamais tirer sur les arceaux pour éviter la désolidarisation.
- 4 – Introduire chaque extrémité d'arceau dans les goupilles ; monter les arceaux en les arc-boutant avant de les introduire à leur deuxième extrémité.
- 5 – Fermer la porte et piqueter la tente au sol en commençant par les extrémités.
- 6 – Accrocher la tente intérieure.
- 7 – Haubaner la tente.

NB : Un mauvais piquetage ainsi qu'un haubanage insuffisant peuvent être la cause d'entrées d'eau. Pensez-donc à vérifier vos tensions régulièrement.

## TENT ERECTION INSTRUCTIONS

- 1 – Joint the 3 interlocked poles.
- 2 – Lay the flysheet on the floor.
- 3 – Take care to stay flat and feed the 3 poles in the sleeves. Never pull the poles to keep them interlocked.
- 4 – Insert each end pole onto pin fixing ; erect the poles by arching them before inserting them at their second end.
- 5 – Close the door and peg out the tent by beginning by the outer parts.
- 6 – Erect the innertent.
- 7 – Guy the ropes.

- A** 2 arceaux - 9 sections - 415 cm - ø 7,9 mm  2 poles
- B** 1 arceau - 7 sections - 360 cm - ø 7,9 mm  1 pole

