

TRIGANO

CEYLAN

NOTICE DE MONTAGE

- 1 - Assembler les 3 arceaux solidarisés.
- 2 - Prendre le double toit, désolidariser les boucles plastique à ouverture rapide des sangles de liaison.
- 3 - Étaler le double toit sur le sol.
- 4 - Introduire dans leurs fourreaux respectifs, en restant bien à plat, les 3 arceaux. Ne jamais tirer sur les arceaux pour éviter la désolidarisation.
- 5 - Introduire chaque extrémité d'arceau dans les goupilles ; monter les arceaux en les arc-boutant avant de les introduire à leur deuxième extrémité.
- 6 - Solidariser les boucles à ouverture rapide aux sangles de liaison.
- 7 - Fermer la porte et piquer la tente au sol en commençant par les extrémités.
- 8 - Accrocher la tente intérieure.
- 9 - Haubaner la tente.

ERECTION INSTRUCTIONS

- 1 - Joint the 3 interlocked poles.
- 2 - Take the flysheet and disconnect the black tape buckles.
- 3 - Lay the flysheet on the floor.
- 4 - Take care to stay flat and feed the 3 poles in the sleeves. Never pull the poles to keep them interlocked.
- 5 - Insert each end pole onto pin fixing; erect the poles by arching them before inserting them at their second end.
- 6 - Reconnect both the black tape buckles.
- 7 - Close the door and peg out the tent by beginning by the outer parts.
- 8 - Erect the innertent.
- 9 - Guy the ropes.

