

TRIGANO

TONGA 6

NOTICE DE MONTAGE

- 1 – Assembler les 4 arceaux solidarisés.
- 2 – Etaler le double toit sur le sol.
- 3 – Introduire dans leurs fourreaux respectifs, en restant bien à plat, les 4 arceaux. Ne jamais tirer sur les arceaux pour éviter la désolidarisation.
- 4 – Introduire chaque extrémité d'arceau dans les œillets. Monter les arceaux en les arc-boutant avant de les introduire dans leur deuxième extrémité.
- 5 – Fermer la porte et piqueter la tente au sol en commençant par les extrémités.
- 6 – Accrocher les tentes intérieures.
- 7 – Haubaner.

ERECTION INSTRUCTIONS

- 1 – Joint the 4 interlocked poles.
- 2 – Lay the flysheet on the floor.
- 3 – Take care to stay flat and insert the 4 poles in the sleeves. Never pull the poles to keep them interlocked.
- 4 – Insert each pole end into pin fixing, erect the poles by arching them before inserting them in their 2nd end.
- 5 – Close the door and peg out the tent by beginning by outer parts.
- 6 – Hang the inner tents.
- 7 – Guy the ropes.

NB : Un mauvais piquetage ainsi qu'un haubanage insuffisant peuvent être la cause d'entrées d'eau. Pensez donc à vérifier vos tensions régulièrement.

A 4 arceaux  4 poles

